Activity	Aug-15
	21-80A
	2
1 Purge & Isolate	
2 Clean down units	
3 Remove all coupling guards & spacers	
4 Carry out as found alignment checks	
HP UNIT	
5 Remove all instrumentation	
6 Remove all necessary seal pipework	
7 Assemble special tooling	
8 Remove shear and spacer rings	
9 Pull the catridge	
10 Transport to DRPH workshop	
11 Clean and preserve the casing	
LP UNIT	
12 Remove suction and discharge spools	
13 Remove all necessary seal piping	
14 Remove all instrumentation	
15 Disconnect casing drains	
16 Unfasten casing holding down bolts	
17 Remove catwalk sections	
18 Lift casing onto support stand	
19 Remove shear and spacer rings	
20 Assemble special tooling	
21 Pull bundle catridge	
22 Transport to DRPH workshop	
23 Clean and preserve the casing	
MP UNIT	
24 Remove all necessary seal piping	
25 Remove all instrumentation	
26 Remove shear and spacer rings	
27 Assemble special tooling	
28 Pull bundle catridge	
29 Transport to DRPH workshop	
Dailoco odt organization but and in the	

MARRENA 1. E

5101 to 1015